

For PS4/PS3/

iOS/PC/Android

Game Controller

WIRELESS CONTROLLER

Instruction Manual - EN



Applicable & Feature function

Please read this manual and any manuals for compatible hardware carefully before using this product. Retain the instructions for future reference.

Battery life and duration

- Do not dispose of damaged or leaking lithium-ion batteries
- Battery life is limited. Battery life will gradually decrease with repeated use and over time. Battery life also varies depending on storage methods, usage conditions and environmental factors.
- Charge in an environment with a temperature range of 10°C - 30°C (50F - 86F). Charging in other environments may not be as effective.
- When the wireless controller is not used for an extended period of time, it is recommended that it be charged at least once a year to help maintain battery function.

Use and handling precautions

- Avoid prolonged use of this product. Take a break at about 30 minutes intervals.
- Stop using this unit immediately if you begin to feel tired or if you experience discomfort or pain in your hands or arms during use. If the condition persists, consult a doctor.
- Permanent hearing loss may occur if the headset or headphones are used at high volume. Set the volume to a safe level. Over time, increasingly loud audio may start to sound normal but can actually be damaging your hearing. If you experience ringing or any discomfort in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the sooner your hearing could be affected. To protect your hearing:
 - Limit the amount of the time you use headset or headphones at high volume.
 - Avoid raising the volume to block out noisy surroundings.
 - Lower the volume if you can't hear people speaking near you.
- Avoid looking into the light bar or the controller when it is flashing. Stop using the controller immediately if you experience any discomfort or pain in any body parts.
- This product is intended for use with the hands only.
- The vibration function of this product may aggravate injuries. Do not use the vibration function if you have any ailment or injury to the bones, joints, or muscles of your hands or arms.
- Note that some software titles enable the vibration function by default. To disable the vibration function, select  (Settings) ➡ [Devices] ➡ [Controllers] from the function screen, and then remove the checkmark from [Enable Vibration]
 - Do not expose the product to high temperatures, high humidity or direct sunlight.
 - Do not allow the product to come into contact with liquids.
 - Do not put heavy objects on the product.
 - Do not throw or drop the product or subject it to strong physical shock.
 - When using the motion sensor function, be cautious of the following points. If the controller hits a person or object, this may cause accidental injury or damage.
 - Before using, check that there is plenty of space around you.
 - When using the controller, grip it firmly to make sure it cannot slip out of your hand.
 - If using a controller that is connected to the PS4 system with a USB cable, make sure there is enough space for the cable so that the cable will not hit a person or object. Also, take care to avoid pulling the cable out of the PS4 system while using the controller.

Exterior protection

Follow the instructions below to help prevent the product exterior from deteriorating or becoming discolored.

- Do not place any rubber or vinyl materials on the product exterior for an extended period of time.
- Use a soft, dry cloth to clean the product.
- Do not use solvents or other chemicals. Do not wipe with a chemically-treated cleaning cloth.

How to register/pair the controller?

The first time you use the controller, or when you want to use the controller on another Playstation 4 system, you must perform device registration (pairing). Turn on the PS4 system and connect the controller to the system with the USB cable to complete device registration.



To a USB port on the PS4 console
USB cable (supplied with the PS4 system)

HINT

For the details about using the controller, refer to the user's guide of the PS4 console.

We recommend using the USB cable for pairing when connecting for the first time

Electrical Parameters:

Input power rating:	DC 5V $\approx$ 800mA
Battery type:	Built-in rechargeable Lithium-Ion battery
Voltage:	DC 3.7 V $\approx$
Battery capacity:	600 mAh
Operating temperature:	5°C - 35°C (41°F - 95°F)

Design and specifications are subject to change without notice.

FCC ID Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, it is recommended that the user attempt to eliminate the interference by doing one or more of the following: - Reorient or position the receiving antenna. Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Seek assistance from your dealer or an experienced radio/TV technician. **IMPORTANT:** Changes or modifications not expressly approved by the manufacturer responsible for compliance may void the user's authority to operate the equipment.

Package list:



Gamepad x1



Charging cable x 1



User Manual x 1

Customer Service:

Due to the official game platform software upgrades or source code changes and other not resist factors caused some of the games cannot be played or connected with our Gamepad, please kindly visit our website: <http://www.sakoglobal.com>, or contact us by email cs@sakoglobal.com for help.

Contact us



www.ishakomall.com



cs@sakoglobal.com



[@Ishakomall](#)

Join us for extra warranty or free gift

For PS4/PS3/
iOS/PC/Android

Mando de juego

CONTROL INALÁMBRICO

Manual de instrucciones - ES



Función aplicable y características

Por favor, lee este manual y cualquier manual de hardware compatible cuidadosamente antes de usar este producto. Guarda las instrucciones para futuras consultas.

Duración y vida útil de la batería

- No deseches las baterías de iones de litio dañadas o que estén filtrando.
- La vida útil de la batería es limitada. Con el uso repetido y el paso del tiempo, la vida útil de la batería disminuirá gradualmente. La duración de la batería también varía según los métodos de almacenamiento, las condiciones de uso y los factores ambientales.
- Carga en un entorno con un rango de temperatura de 10°C - 30°C (50°F - 86°F). Cargar en otros entornos puede no ser tan efectivo.
- Cuando el controlador inalámbrico no se use durante un período prolongado, se recomienda cargarlo al menos una vez al año para ayudar a mantener la función de la batería.

Precauciones de uso y manipulación

- Evite el uso prolongado de este producto. Tome descansos cada aproximadamente 30 minutos.
- Deje de usar esta unidad inmediatamente si comienza a sentirse cansado/a o si experimenta molestias o dolor en las manos o brazos durante su uso. Si la condición persiste, consulte a un médico.
- Puede producirse pérdida permanente de la audición si se utiliza el auricular o los auriculares a un volumen alto. Ajuste el volumen a un nivel seguro. Con el tiempo, el audio cada vez más fuerte puede parecer normal, pero en realidad puede dañar su audición. Si experimenta zumbidos u alguna molestia en los oídos o dificultad para oír, deje de escuchar y hágase revisar la audición. Cuanto más alto sea el volumen, más pronto se verá afectada su audición. Para proteger su audición:
 - Limite el tiempo de uso de los auriculares o auriculares a un volumen alto.
 - Evite aumentar el volumen para bloquear ruidos del entorno.
 - Baje el volumen si no puede escuchar a las personas que están cerca de usted.
- Evite mirar la barra de luz o el controlador cuando estén parpadeando. Deje de usar el controlador inmediatamente si experimenta alguna molestia o dolor en alguna parte del cuerpo.
- Este producto está destinado a ser utilizado solo con las manos.
- La función de vibración de este producto puede agravar lesiones. No utilice la función de vibración si tiene alguna enfermedad o lesión en los huesos, articulaciones o músculos de las manos o brazos.
- Tenga en cuenta que algunos títulos de software activan la función de vibración de forma predeterminada. Para desactivar la función de vibración, seleccione  (Configuración) ➡ [Dispositivos] ➡ [Controladores] desde la pantalla de funciones y luego desmarque [Activar vibración].
- No exponga el producto a altas temperaturas, alta humedad o luz solar directa.
- No permita que el producto entre en contacto con líquidos.
- No coloque objetos pesados sobre el producto.
- No arroje ni deje caer el producto ni lo someta a golpes físicos fuertes.
- Al utilizar la función del sensor de movimiento, tenga cuidado con los siguientes puntos. Si el controlador golpea a una persona u objeto, esto puede causar lesiones o daños accidentales.

Antes de usarlo, asegúrese de que haya suficiente espacio a su alrededor.

Al usar el controlador, agárrelo firmemente para asegurarse de que no se resbale de su mano.

Si está utilizando un controlador conectado al sistema PS4 con un cable USB, asegúrese de que haya suficiente espacio para el cable para que no golpee a una persona u objeto. Además, tenga cuidado de evitar que el cable se desconecte del sistema PS4 mientras usa el controlador.

Protección exterior

Sigue las instrucciones a continuación para ayudar a prevenir el deterioro o decoloración del exterior del producto.

- No coloques ningún material de goma o vinilo en el exterior del producto durante un período prolongado.

- Utiliza un paño suave y seco para limpiar el producto.
- No utilices solventes u otros productos químicos. No limpies con un paño de limpieza tratado químicamente.

¿Cómo registrar/vincular el controlador?

La primera vez que uses el controlador, o cuando quieras usar el controlador en otro sistema PlayStation 4, debes realizar el registro del dispositivo (emparejamiento). Enciende el sistema PS4 y conecta el controlador al sistema con el cable USB para completar el registro del dispositivo.



A un puerto USB en la consola PS4
Cable USB (suministrado con el sistema PS4)

CONSEJO

Para obtener más detalles sobre cómo utilizar el controlador, consulte la guía del usuario de la consola PS4.

Se recomienda utilizar el cable USB para el emparejamiento cuando se conecta por primera vez

FCC ID Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, it is recommended that the user attempt to eliminate the interference by doing one or more of the following: - Reorient or position the receiving antenna. Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Seek assistance from your dealer or an experienced radio/TV technician. **IMPORTANT:** Changes or modifications not expressly approved by the manufacturer responsible for compliance may void the user's authority to operate the equipment.

Parámetros eléctricos:

Potencia de entrada:	DC 5V --- 800mA
Tipo de batería:	Batería de iones de litio recargable incorporada
Voltaje:	DC 3.7 V ---
Capacidad de la batería:	600 mAh
Temperatura de funcionamiento:	5°C - 35°C (41°F - 95°F)

El diseño y las especificaciones están sujetos a cambios sin previo aviso.

Lista de paquetes:



Gamepad x1



Charging cable x 1



User Manual x 1

Servicio al cliente:

Debido a las actualizaciones oficiales del software de la plataforma de juegos o cambios en el código fuente y otros factores no controlables, algunos juegos pueden no poder jugarse o conectarse con nuestro Gamepad. Te invitamos a visitar amablemente nuestro sitio web: <http://www.sakoglobal.com>, o contáctanos por correo electrónico a cs@sakoglobal.com para obtener ayuda.

Contáctanos



www.ishakomall.com



cs@sakoglobal.com



[@Ishakomall](https://www.facebook.com/ishakomall)

Únase a nosotros para obtener una garantía adicional o regalos